

TRANSCOOL


PORTABLE 12 VOLT EVAPORATIVE COOLER

IMPORTANT NOTES - READ BEFORE USE

CHILDREN MUST BE SUPERVISED WHEN NEAR THE UNIT


ALWAYS OPERATE IN A WELL VENTILLATED AREA, IN AN UPRIGHT POSITION ON A LEVEL SURFACE

ADDING WATER - SLIDE FILLER LID TOWARD REAR OF UNIT TO OPEN AND ADD WATER
NEVER OVERFILL PAST 'FULL' MARK ON WATER LEVEL WINDOW




No damage will result if the unit is used without water -- When using in a moving vehicle, only half fill and secure unit
Only half fill with water when using ice -- When adding ice, keep ice level below bottom of vents inside the unit
If using external water tank situate it at a higher level than the E3 unit to allow water to gravity feed into unit via hose

OPERATION - PLUG UNIT INTO CIGARETTE SOCKET (12V)
OR WALL SOCKET (110-240V) AND TURN FAN SWITCH CLOCKWISE




SPECIFICATIONS

WEIGHT:
1.5KG
WATER CAPACITY:
1.8L INTERNAL, 5L EXTERNAL
CURRENT DRAW:
LOW 0.7AMP, HIGH 1.7AMP



**AIRFLOW
ADJUSTMENT**
THE TRANSCOOL E3
IS A PERSONAL SPOT
COOLER, VENTS
MUST BE DIRECTED
TOWARDS THE USER



ALLOW 30 MINUTES FOR NEW OR DRY COOLING PAD TO ACHIEVE MAXIMUM COOLING

DRAIN WATER TANK AFTER USE BY TIPPING FORWARD TO ALLOW WATER TO RUN OUT OF FRONT VENTS

DRY INTERNAL COOLING PAD BEFORE STORING

EMPTY WATER AND RUN UNIT UNTIL INTERNAL BLUE COOLING PAD IS DRY TO TOUCH

EVAPORATIVE COOLING CAN BE LESS EFFECTIVE IN AREAS OF HIGH HUMIDITY - THE E3 CAN BE USED WITHOUT WATER IN AREAS OF HIGH HUMIDITY

ADD 2-5ML OF EUCALYPTUS OR TEA TREE OIL TO WATER FOR ANTIBACTERIAL PURPOSES AND FRESH SMELL

THE TRANSCOOL E3 IS FITTED WITH INTERNAL LOW BATTERY VOLTAGE CUTOUT

IF RED LIGHT DOES NOT ILLUMINATE ON E3 12V CIGARETTE PLUG, FUSE MAY NEED REPLACING

To replace fuse (12V, 2AMP, located in 12V cigarette plug) - undo knurled nut on tip of cigarette socket, remove and inspect fuse, replace if necessary, tighten knurled nut



DANGER!


KEEP HANDS, HAIR AND ALL OBJECTS AWAY
FROM FAN AIR INTAKE AT REAR OF UNIT

TRANSCOOL

PORTABLE 12 VOLT EVAPORATIVE COOLER

IMPORTANT NOTES - READ BEFORE USE

REPLACING COOLING PADS - REPLACE COOLING PADS EVERY 500-800 HOURS, DEPENDING ON ENVIRONMENTAL CONDITIONS. REPLACEMENT PADS CAN BE PURCHASED ON OUR WEBSITE
COOLING PAD MAY BE WASHED IN WARM SOAPY WATER WHEN NECESSARY



WARRANTY

DONEGAN ASSISTANCE GROUP warrants 24 months from date of purchase any Transcool E3 that does not perform correctly due to defects caused by faulty workmanship or materials. Our obligation assumed under this warranty is to the repair or replacement of parts without charge, which are defective and have not been misused, carelessly handled or defaced by repairs made or attempted by others. Consequential damages to this product are not covered. To notify us about a warranty issue email or call us and we will arrange to send you a return postage label if the warranty period is still valid. The return postage label is valid for 7 days after you notify us of claim.



DONEGAN ASSISTANCE GROUP PTY LTD

PO Box 173 Kyneton, Victoria, 3444

Phone: 1300 812 005

Email: sales@transcool.info

Website: www.transcool.info